



Installation Guide

DEVIreg™ Touch

Electronic Intelligent Timer Thermostat

www.DEVI.com

DEVI® 
by Danfoss

Table of Contents

1	Introduction	3
	1.1 Technical Specifications	4
	1.2 Safety Instructions	7
2	Mounting Instructions	8
3	Settings	12
	3.1 Initial Settings.	12
	3.2 Forecast.	16
	3.3 Window Open.	18
	3.4 Maximum Floor Temperature	19
4	Symbols	23
5	Warranty.	24
6	Disposal Instruction	26

1 Introduction

DEVIreg™ Touch is an electronic programmable timer thermostat used for controlling electrical floor heating elements. The thermostat is designed for fixed installation only and can be used for both direct heating of the entire room and for comfort heating of the floor. Among others, the thermostat has the following features:

- A touchscreen display with backlight.
- An easy-to-follow menu-driven programming and operation.


- An installation wizard with room/floor type-specific setup.
- Support for multiple frame systems.
- Compatible with several 3rd party NTC sensors.
- Thermostat settings can be specified before installation and imported to the thermostat using a web-generated code, or copied from a thermostat in a similar installation.
- Smart access to thermostat settings after installation by using a web code interface for easy setup or remote troubleshooting.

**More information on this product can also be found at:
touch.devi.com**

1.1 Technical Specifications

Operation voltage	220-240 V~, 50/60 Hz
Standby power consumption	Max. 0.40 W
Relay: Resistive load Inductive load	Max. 16 A / 3680 W @ 230 V cos φ= 0.3 Max. 1 A

Sensing units	<p>NTC 6.8 kOhm at 25°C NTC 10 kOhm at 25°C NTC 12 kOhm at 25°C NTC 15 kOhm at 25°C (Default) NTC 33 kOhm at 25°C NTC 47 kOhm at 25°C</p>
<p>Sensing values: (Default NTC 15 K) 0°C 20°C 50°C</p>	<p>42 kOhm 18 kOhm 6 kOhm</p>
Control	PWM (Pulse Wide Modulation)
Ambient temperature	0° to +30°C
Frost protection temperature	5°C to +9°C (default 5°C)
Temperature range	<p>Room temperature: 5-35°C. Floor temperature: 5-45°C. Max. floor: 20-35°C (if unrecoverable seal is broken then up to 45°C). Min. floor: 10-35°C, only with combination of room and floor sensor.</p>
Sensor failure monitoring	The thermostat has a built-in monitoring circuit, which will switch off the heating if the sensor is disconnected or short-circuited

Cable specification max.	1x4 mm ² or 2x2,5 mm ²
Ball pressure test temperature	75°C
Pollution degree	2 (domestic use)
Controller type	1C
Software class	A
Storage temperature	-20°C to +65°C
IP class	21
Protection class	Class II - 
Dimensions	85 x 85 x 20-24 mm (in-wall depth: 22 mm)
Weight	103 g

Electrical safety and Electro-Magnetic Compatibility for this product is covered by the compliance with the EN/IEC Standard "Automatic electrical controls for household and similar use":

- EN/IEC 60730-1 (general)
- EN/IEC 60730-2-9 (thermostat)

1.2 Safety Instructions

Make sure the mains supply to the thermostat is turned off before installation.

IMPORTANT: When the thermostat is used to control a floor heating element in connection with a wooden floor or similar material, always use a floor sensor and never set the maximum floor temperature to more than 35°C.

Please also note the following:

- The installation of the thermostat must be done by an authorized and qualified installer according to local regulations.
- The thermostat must be connected to a power supply via an all-pole disconnection switch.
- Always connect the thermostat to continuous power supply.
- Do not expose the thermostat to moisture, water, dust, and excessive heat.

2 Mounting Instructions

Please observe the following placement guidelines:



Place the thermostat at a suitable height on the wall (typically 80-170cm.).



The thermostat should not be placed in wet rooms. Place it in an adjacent room. Always place the thermostat according to local regulation on IP classes.



Do not place the thermostat on the inner side of an exterior wall.



Always install the thermostat at least 50 cm. from windows and doors.



Do not place the thermostat in a way that it will be exposed to direct sunlight.



Note: A floor sensor enables a more accurate temperature control and is recommended in all floor heating applications and **mandatory** under wooden floors to reduce the risk of over-heating the floor.

- Place the floor sensor in a conduit in an appropriate place where it is not exposed to sunlight or draft from door openings.
- Equally distant and >2cm from two heating cables.
- The conduit should be flush with the floor surface - countersink the conduit if necessary.
- Route the conduit to the connection box.
- The bending radius of the conduit must be min 50mm.

Follow the steps below to mount the thermostat:


1. Open the thermostat:

Important: Do NOT press on the display screen when removing the front part.

Press your fingers under the side of the front part and pull toward you:



2. Connect the thermostat according to the connection diagram.



The screen of the heating cable must be connected to the earth conductor of the power supply cable by using a separate connector.

Note: Always install the floor sensor in a conduit in the floor.

3. Mount and reassemble the thermostat.



- Fasten the thermostat to a socket or an exterior wall box by driving the screws through the holes in each side of the thermostat.
- Put the frame on.
- Click the display module back in place.

Important: Do NOT press on the display screen when clicking the display module back in place.


Initially main supply the thermostat for 15 hours to fully charge the battery. The current time and day is then kept for 24 hours if mains supply is off. All other settings are stored permanently.

3 Settings


3.1 Initial Settings

Initial settings must be specified when the unit is activated for the first time:



1. Use the arrows in the right side of the screen to go to your language, and press to select it. Then press in the upper right corner to confirm.




2. Press the hour numbers and use the < and > arrows to set the hour. Press to confirm.




3. Press the minutes numbers and use the < and > arrows to set the minutes. Press to confirm. Press again to go to the **SET DATE** screen.


- Press the day, month and year respectively and set the date using the < and > arrows and pressing  to confirm. When the date is correct, press , to confirm on the **SET DATE** screen.





- If you have already made the installation setup online, press **ENTER CODE** and go directly to Step 13 now. Otherwise press **SETUP WIZARD** and go to Step 6.




- On the **SETUP** information screen, press  to start.





- Use the < and > arrows to select whether only a floor sensor or a combination of room and floor sensors should be used. Press  to confirm.






Note: A “room only” option may also be available. For details, see the “Maximum Floor Temperature” section.


8. Use the < and > arrows to select the installed floor sensor type. (Measured resistance and corresponding temperature are shown in brackets). Press  to confirm.

9. Use the < and > arrows to select the flooring type. Press  to confirm.


10. Use the < and > arrows to select the room type. Press  to confirm.



11. Use the < and > arrows to select the approximate load of the heating element. If an external relay is used or the installed output is unknown, select the «- -» option. Press to confirm.



12. Use the < and > arrows to select whether the timer should be activated or not. Press to confirm and end the initial thermostat setup. Skip Step 13.



13. Enter your web-generated code. Then press to end the initial thermostat setup. If no check mark () appears, the hexacode is incorrect.



3.2 Forecast

The forecast feature is used when you switch between economy temperature and comfort temperature. If forecast

is turned on, heating will start so that the requested temperature is reached at the specified time.

For example, if your comfort temperature is set to 22°C and the comfort period starts at 6.00 o'clock am, heating will start before 6 o'clock so that your room temperature will be 22°C at 6 o'clock. If forecast is turned off, heating will not start until 6 o'clock and it will take a while to reach a room temperature of 22°C.


The forecast feature also optimises heating stop when switching from comfort temperature to economy temperature.


How to turn the forecast feature on and off.


1. Touch the thermostat display to activate it, then press **menu**.




2. Press **SETTINGS** in the bottom right corner of the menu. Then press **OPTIONS**.



3. Press **FORECAST**. Then press **ON** to optimise heating start/stop or **OFF** to simply let the heating start/stop at the specified time. Press  to confirm.





To return to the normal temperature display, press the back arrow in the upper left corner of the screen until you get to the main menu, then press .

3.3 Window Open


How to turn “window open detection” on or off

1. Touch the thermostat display to activate it, then press **menu**.
2. Press **SETTINGS** in the bottom right corner of the menu. Then press **OPTIONS**.



3. Press **WINDOW OPEN**. Then press **ON** to temporarily turn off heating in case of a sudden temperature drop in the room or **OFF** to let the thermostat heat during sudden temperature drops in the room. Press  to confirm.



To return to the normal temperature display, press the back arrow in the upper left corner of the screen until you get to the main menu, then press .


3.4 Maximum Floor Temperature

How to set the maximum floor temperature


1. Touch the thermostat display to activate it, then press **menu**.




2. Press **SETTINGS** in the bottom right corner of the menu. Then press **INSTALLATION** and **MANUAL SETUP**.




3. Press **MAX. FLOOR**. Then use the < and > arrows to set the allowed maximum floor temperature. Press to confirm.



To return to the normal temperature display, press the back arrow in the upper left corner of the screen until you get to the main menu, then press .

If you break the small plastic seal on the back of the display module, e.g. using a screwdriver, it will be possible to set the maximum floor temperature up to 45°. Furthermore, it will be possible to use only a room sensor. However, this option is not recommendable due to an increased risk of overheating the floor.



IMPORTANT: When the thermostat is used to control a floor heating element in connection with a wooden floor or similar material, always use a floor sensor and never set the maximum floor temperature to more than 35°C.




Note: Please contact the floor supplier before changing the maximum floor temperature and be aware of the following:

- The floor temperature is measured where the sensor is placed.
- The temperature of the bottom of a wooden floor can be up to 10 degrees higher than the top.
- Floor manufactures often specify the max. temperature on the top surface of the floor.

Thermal resist- ance [m²K/W]	Examples of flooring	Details	Approximate setting for 25 °C floor tem- perature
0.05	8 mm HDF based laminate	> 800 kg/m ³	28 °C
0.10	14 mm beech parquet	650 - 800 kg/m ³	31 °C
0.13	22 mm solid oak plank	> 800 kg/m ³	32 °C
< 0.17	Max. carpet thickness suitable for floor heating	acc. to EN 1307	34 °C
0.18	22 mm solid fir planks	450 - 650 kg/m ³	35 °C

4 Symbols

The following symbols may appear in the upper left corner of the temperature display:

Symbol	What it means
	The thermostat is in manual mode, i.e. the timer function is off. The timer lets you automatically switch between economy and comfort temperatures according to a predefined schedule.
	An away period has been planned. On the date of departure, the away period starts at 00:00 and the specified away temperature will be maintained 24 hours a day until the date of return at 00:00. At this time the normal temperature settings will resume.
	An error has occurred. If you press the warning symbol, more information on the error will appear.

5 Warranty

A 5-year product warranty is valid for:

- thermostats: DEVireg™ Touch.

Should you, against all expectations, experience a problem with your DEVI product, you will find that Danfoss offers DEVIwarranty valid from the **date of purchase** on the following conditions: During the warranty period Danfoss shall offer a new comparable product or repair the product if the product is found to be faulty by reason of defective design, materials or workmanship. The repair or replacement.

The decision to either repair or replace will be solely at the discretion of Danfoss. Danfoss shall not be liable for any consequential or incidental damages including, but not limited to, damages to property or extra utility expenses. No extension of the warranty period following repairs undertaken is granted.

The warranty shall be valid only if the WARRANTY CERTIFICATE is completed correctly and in accordance with the instructions, the fault is submitted to the installer or the seller without undue delay and proof of purchase is provided. Please note that the WARRANTY CERTIFICATE must be filled in, stamped and signed by the authorized installer performing the installation (Installation date must be indicated). After the installation is performed, store and keep the WARRANTY CERTIFICATE and purchase documents (invoice, receipt or similar) during the whole warranty period.

DEVIwarranty shall not cover any damage caused by incorrect conditions of use, incorrect installation or if installation has been carried out by non-authorized electricians. All work will be invoiced in full if Danfoss is required to inspect or repair faults that have arisen as a result of any of the above. The DEVIwarranty shall not extend to products which have not been paid in full. Danfoss will, at all times, provide a rapid and effective response to all complaints and inquiries from our customers.

The warranty explicitly excludes all claims exceeding the above conditions.

For full warranty text visit **www.devi.com**.
devi.danfoss.com/en/warranty/

WARRANTY CERTIFICATE

The DEVI warranty is granted to:

Address _____ Stamp _____

Purchase date _____

Serial number of the product _____

Product _____ Art. No. _____

*Connected output [W] _____

Installation Date & Signature _____ Connection Date & Signature _____

**Not mandatory*



6 Disposal Instruction



Danfoss A/S

Nordborgvej 81
6430 Nordborg, Syddanmark
Denmark

Danfoss A/S


DEVI • devt.com • +45 7488 2222 • EH@danfoss.com

Any information, including, but not limited to information on selection of product, its application or use, product design, weight, dimensions, capacity or any other technical data in product manual, catalogues descriptions, advertisements, etc. and whether made available in writing, orally, electronically, online or via download, shall be considered informative, and is only binding if and to the extent, explicit reference is made in a quotation or order confirmation. Danfoss can not accept any responsibility for possible errors in catalogues, brochures, videos and other material. Danfoss reserves the right to alter its products without notice. This also applies to products ordered but not delivered provided that such alterations can be made without changes to form, fit or function of the product.

All trademarks in this material are property of Danfoss A/S or Danfoss group companies. Danfoss and the Danfoss logo are trademarks of Danfoss A/S. All rights reserved.

DEVreg™ Touch - Polar White

140F1071



Design Frame
Intelligent Timer
Thermostat
Floor / Room Sensor
220-240V~
50-60Hz
0 to +30°C
16A/3680W@230V~
IP 21



Product documentation

* 0 7 8 0 6 0 8 0 0 *



For UK customer only: Importer:
Danfoss Ltd., 22 Wycombe End, HP9 1NB, GB

Designed in Denmark for Danfoss A/S



5 703466 225615